

Capsule Filter



Use this guide to find the end fittings that will fit your connections. The codes to use for your inlet and outlet fittings when ordering your capsule filter are shown in the list below. Reference our individual product data sheets to find detailed ordering information.



1/4" Female NPT



1/4" Male NPT



3/8" Female NPT



1/2" Female NPT



1/2" Male NPT



1" Sanitary*



Hose Barb**



1 1/2" Sanitary with Side Vent



1/2" Single Stepped Barb with Side Vent



6mm Quick Disconnect



3/4" Single Step Barb with Side Vent

Outer

Diameter

Inner

Diameter



Compression (JACO)

Maximum

9/16"

(14.0 mm)

13/32"

(10.55 mm)

*Fits 1	' or 1/2" Sanitary Gaskets/0	lamps
**Tap	ered Hose Barb Diameter R	anges

End Fitting Codes and Options

Inlet

A = 1/4" FNPT

B = 1/4" MNPT

C = 3/8" FNPT

D= 1/2" FNPT**E** = 1/2" MNPT

F = 1" Sanitary

G = Stepped Hose Barb

H = 1 1/2" Sanitary with

Side Vent

I = 1/2" Single Stepped Barb with Side Vent

Y = Compression (JACO)

Z = 6mm Quick Disconnect

Outlet

A = 1/4" FNPT

B = 1/4" MNPT

C = 3/8" FNPT

D= 1/2" FNPT

E = 1/2" MNPT

F = 1" Sanitary

G = Stepped Hose Barb

H = 1 1/2" Sanitary with

Side Vent

I = 1/2" Single Stepped Barb with Side Vent & Filling Bell

Y = Compression (JACO)

Z = 6mm Quick Disconnect



Minimum

11/32"

(8.6 mm)

5/32"

(4.0 mm)