

Use this guide to find the end fittings that will fit your connections. The codes to use for your inlet and outlet fittings when ordering your capsule filter are shown in the list below. Reference our individual product data sheets to find detailed ordering information.



1/4" Female NPT



1/4" Male NPT



3/8" Female NPT



1/2" Female NPT



1/2" Male NPT



1"-1 1/2" Sanitary\*



Hose Barb\*\*

\*Fits 1" or 1 1/2" sanitary gaskets/clamps

## \*\*Tapered Hose Barb Diameter Ranges:

	Minimum	Maximum
Outer Diameters	11/32" (8.6mm)	9/16" (14.0mm)
Inner Diameters	5/32" (4.0mm)	13/32" (10.55mm)

## **End Fitting Codes**

A = 1/4" Female NPT

B = 1/4" Male NPT

C = 3/8" Female NPT

D = 1/2" Female NPT

E = 1/2" Male NPT

F = 1"-1 1/2" Sanitary\*

G = Hose Barb\*\*

## Outlet

A = 1/4" Female NPT

B = 1/4" Male NPT

C = 3/8" Female NPT

D = 1/2" Female NPT

E = 1/2" Male NPT

F = 1"-1 1/2" Sanitary\*

G = Hose Barb\*\*



One Chestnut Street Nashua, NH 03060 603.880.4420 FAX: 603.880.4536

CriticalProcess.com

The information contained herein is subject to change without notice. The Critical Process Filtration logo is a trademark of Critical Process Filtration, Inc. © 2020 Critical Process Filtration, Inc. • All Rights Reserved

Capsule End Fitting Guide Rev-