

Use this guide to find the end fittings that will fit your connections. On the Micro Capsule's datasheet, fill in the appropriate end fitting code listed below when creating your part number. Photos represent outlet configurations with Luer Lock vent ports.



1/8" Hose Barb



1/4" Hose Barb



1/2" Hose Barb



Luer Lock



1/2" Sanitary*



1/4" MNPT

End Fitting Codes

Inlet	Inlet Vent Port	Outlet	Outlet Vent Port
1 = 1/8" Hose Barb	1 = 1/8" Hose Barb	1 = 1/8" Hose Barb	1 = 1/8" Hose Barb
2 = 1/4" Hose Barb	2 = 1/4" Hose Barb	2 = 1/4" Hose Barb	2 = 1/4" Hose Barb
3 = 1/2" Hose Barb	3 = 1/2" Hose Barb	3 = 1/2" Hose Barb	3 = 1/2" Hose Barb
4 = Luer Lock	4 = Luer Lock	3B = 1/2" Hose Barb	4 = Luer Lock
5 = 1/2" Sanitary*	6 = 1/4" MNPT	with Filling Bell	6 = 1/4" MNPT
6 = 1/4" MNPT		4 = Luer Lock	
		5 = 1/2" Sanitary*	



One Chestnut Street Nashua, NH 03060 603.880.4420 FAX: 603.880.4536

CriticalProcess.com

The information contained herein is subject to change without notice. The Critical Process Filtration logo is a trademark of Critical Process Filtration, Inc.

© 2025 Critical Process Filtration, Inc. • All Rights Reserved

Micro Capsule End Fitting Guide Rev-

6 = 1/4" MNPT

^{*}When choosing the sanitary inlet/outlet, the Luer Lock option is required for the Vent Port